



**VEXCEL**  
IMAGING

# ULTRACAM

## Calibration Report

---



---

**Copyright © 2017 by Vexcel Imaging GmbH, Graz - Austria.**

The contents of this document may not be reproduced in any form or communicated to any third party without the prior written consent of Vexcel Imaging GmbH.

While every effort is made to ensure its correctness, Vexcel Imaging GmbH assumes no responsibility neither for errors and omissions which may occur in this document nor for damage caused by them.

Vexcel Imaging GmbH does not make a commitment to update the information and software discussed in this document.

All mentioned trademarks or registered trademarks are owned by their respective owners.

Printed in Austria at Vexcel Imaging GmbH. All rights reserved.

Bahia, Brasil 2013

Photo on page 1 courtesy of Hiparc Geotecnologia, Brasil

[www.hiparc.com](http://www.hiparc.com)

UltraCam Lp, GSD25 cm, RGB



# ULTRACAM

## Geometric Calibration

---

**Camera:** UltraCam Falcon Prime  
**Serial:** UC-Fp-1-20519084-f100

**Panchromatic Camera:** ck = 100.500 mm  
**Multispectral Camera:** ck = 100.500 mm

**PPA Information:** X: 0.000  
Y: 0.000

**Calibration Date:** Mar-10-2017  
**Date of Report:** Mar-14-2017  
**Camera Revision:** Rev03.00  
**Version of Report:** V01



## Panchromatic Camera

### Large Format Panchromatic Output Image

|                                      |  |                      |                    |
|--------------------------------------|--|----------------------|--------------------|
| <b>Image Format</b>                  | long track                             | 67.860mm             | 11310pixel         |
|                                      | cross track                            | 103.860mm            | 17310pixel         |
| <b>Image Extent</b>                  |  | (-33.930, -51.930)mm | (33.930, 51.930)mm |
| <b>Pixel Size</b>                    |  | 6.000μm*6.000μm      |                    |
| <b>Focal Length</b>                  | ck                                     | 100.500mm            | ± 0.002mm          |
| <b>Principal Point<br/>(Level 2)</b> | X_ppa                                  | 0.000mm              | ± 0.002mm          |
|                                      | Y_ppa                                  | 0.000mm              | ± 0.002mm          |
| <b>Lens Distortion</b>               | Remaining Distortion less than 0.002mm |                      |                    |

## Multispectral Camera


### Medium Format Multispectral Output Image (Upscaled to panchromatic image format)

|                                      |  |                      |                    |
|--------------------------------------|--|----------------------|--------------------|
| <b>Image Format</b>                  | long track                             | 67.860mm             | 3770pixel          |
|                                      | cross track                            | 103.860mm            | 5770pixel          |
| <b>Image Extent</b>                  |  | (-33.930, -51.930)mm | (33.930, 51.930)mm |
| <b>Pixel Size</b>                    |  | 18.000μm*18.000μm    |                    |
| <b>Focal Length</b>                  | ck                                     | 100.500mm            | ± 0.002mm          |
| <b>Principal Point<br/>(Level 2)</b> | X_ppa                                  | 0.000mm              | ± 0.002mm          |
|                                      | Y_ppa                                  | 0.000mm              | ± 0.002mm          |
| <b>Lens Distortion</b>               | Remaining Distortion less than 0.002mm |                      |                    |






## Full Panchromatic Image, Residual Error Diagram



Residual Error (RMS): 0.49  $\mu m$



## Green Cone (Cone 5), Residual Error Diagram



Residual Error (RMS): 0.50  $\mu\text{m}$



## Explanations

### Calibration Method:

The geometric calibration is based on a set of 84 images of a defined geometry target with 394 GCPs.

Number of point measurements for the panchromatic camera : >16000


Number of point measurements for the multispectral camera : >60000

Determination of the image parameters by Least Squares Adjustment.

Software used for the adjustment: BINGO (GIP Eng. Aalen, Germany)

### Level 2 Image Coordinate System:


## Lvl2, Camera prop. Orientation




The image coordinate system of the Level 2 images is shown in the above figure. The basic image format and coordinate of the principal point in the level 2 image is given on page 4 of this report. The above figure shows the position of an example principal point at the coordinate (-0.123 / 0.345).



**Level 3 Image Coordinate System:**  
(after rotation of 270° CW)



Panchromatic Image Format



Multispectral Image Format

**Position of Principal Point in Level 3 Image**

The position of the principal point in the level 3 image depends on the “rotation” setting used in UltraMap during the pan-sharpening step. The exact position relative to the image center is given in the table below as a function of the rotation setting used in UltraMap. The coordinates are specified for clockwise (CW) rotation in steps of 90 degrees, according to the principal point coordinate given on page 4 for high- and low resolution images.


| Image Format | Clockwise Rotation (Degree) | PPA   |       |
|--------------|-----------------------------|-------|-------|
|              |                             | X     | Y     |
| Level 2      | -                           | 0.000 | 0.000 |
| Level 3      | 0                           | 0.000 | 0.000 |
| Level 3      | 90                          | 0.000 | 0.000 |
| Level 3      | 180                         | 0.000 | 0.000 |
| Level 3      | 270                         | 0.000 | 0.000 |






The coordinates in the figure below are only example values to illustrate the effect of image rotation on the principal point position, and do **not** correspond to the camera described in this report.


Lvl3, Rotation 0 deg clockwise




Lvl3, Rotation 90 deg clockwise



Lvl3, Rotation 270 deg clockwise



Lvl3, Rotation 180 deg clockwise





## Lens Resolving Power

The following curves show the development of the modulation transfer function across different image heights of the panchromatic cones.



Please note that these values have been calculated and can vary up to 10% with optics from production (especially at high LP's).

The curves are given for the meridional (tangential) and sagital (radial) component of signals at frequencies of 12.5, 25, 50 and 100 line pairs per millimeter.

As the MTF is a function of the specific aperture size used, one set of curves is given for each aperture size.


### Lens types

| Cone       | Lens   |
|------------|--|
| C0         | Linos Vexcel Apo-Sironar Digital HR 1:5,6/100mm, Linos GmbH, Germany |
| C1         | Linos Vexcel Apo-Sironar Digital HR 1:5,6/100mm, Linos GmbH, Germany |
| C2         | Linos Vexcel Apo-Sironar Digital HR 1:5,6/100mm, Linos GmbH, Germany |
| C3         | Linos Vexcel Apo-Sironar Digital HR 1:5,6/100mm, Linos GmbH, Germany |
| C4 (RED)   | Linos Vexcel Apo-Sironar Digital HR 1:4/33mm, Linos GmbH, Germany    |
| C5 (GREEN) | Linos Vexcel Apo-Sironar Digital HR 1:4/33mm, Linos GmbH, Germany    |
| C6 (BLUE)  | Linos Vexcel Apo-Sironar Digital HR 1:4/33mm, Linos GmbH, Germany    |
| C7 (NIR)   | Linos Vexcel Apo-Sironar Digital HR 1:4/33mm, Linos GmbH, Germany    |






### Modulation versus Image Height - Aperture f / 8





### Modulation versus Image Height - Aperture f / 9.5







## Spectral Sensitivity





# ULTRACAM

## Radiometric Calibration

**Camera:** UltraCam Falcon Prime  
**Serial:** UC-Fp-1-20519084 -f100

| Used Apertures | PAN  | R, G, NIR | B    |
|----------------|------|-----------|------|
|                | F5.6 | F4.8      | F4.8 |
|                | F6.7 | F5.6      | F4.8 |
|                | F8   | F6.7      | F4.8 |
|                | F9.5 | F8        | F5.6 |
|                | F11  | F9.5      | F6.7 |
|                | F13  | F11       | F8   |
|                | F16  | F13       | F9.5 |
|                | F22  | F19       | F13  |










**Calibration Date:** Mar-10-2017  
**Date of Report:** Mar-14-2017  
**Camera Revision:** Rev03.00  
**Version of Report:** V01



## Calibration of Vignetting for working Aperture F6.7

|          | PAN  | R, G, NIR | B    |
|----------|------|-----------|------|
| Aperture | F6.7 | F5.6      | F4.8 |

Graphical Overview of Pan Sensors:

|  |  |  |
|--|--|--|
|   |   |   |
|   |   |   |
|  |  |  |

Graphical Overview of Multispectral Sensors:

|   |   |
|---|---|
|  |  |
|  |  |



## Dead Pixel Report:

| Sensor number |              |              |
|---------------|--------------|--------------|
| Anomaly type  | X-Coordinate | Y-Coordinate |

### C00-00

PIXEL: 811/3399  
PIXEL: 1698/3165  
PIXEL: 1951/ 794  
PIXEL: 3611/1860  
PIXEL: 3732/3098  
PIXEL: 3930/1031  
PIXEL: 4141/1440  
PIXEL: 4769/3177  
PIXEL: 5232/1354  
PIXEL: 5937/2474

### C00-01

PIXEL: 75/3509  
PIXEL: 224/ 655  
PIXEL: 344/3032  
PIXEL: 394/3040  
PIXEL: 691/ 626  
PIXEL: 768/1924  
PIXEL: 1393/3975  
PIXEL: 1567/2498  
PIXEL: 1789/3413  
PIXEL: 1819/3938  
PIXEL: 2466/2730  
PIXEL: 3072/1665  
PIXEL: 3084/ 149  
PIXEL: 3278/3114  
PIXEL: 3496/3504  
PIXEL: 3597/2362  
PIXEL: 3962/ 634  
PIXEL: 4246/3305  
PIXEL: 4699/1706  
PIXEL: 4891/2287  
PIXEL: 5127/1115  
PIXEL: 5547/2251  
PIXEL: 5598/ 424  
PIXEL: 5922/2565  
PIXEL: 5875/3858

### C00-02

PIXEL: 270/ 964





PIXEL: 384/1450  
PIXEL: 399/1475  
PIXEL: 833/ 697  
PIXEL: 1116/2159  
PIXEL: 1228/3277  
PIXEL: 1308/2064  
PIXEL: 1596/ 473  
PIXEL: 2371/3470  
PIXEL: 2407/1271  
PIXEL: 2803/2940  
PIXEL: 3202/3782  
PIXEL: 5412/1716  
PIXEL: 5530/ 928  
PIXEL: 1768/3945

## **C00-03**

PIXEL: 120/ 630  
PIXEL: 568/2579  
PIXEL: 703/ 382  
PIXEL: 1127/2579  
PIXEL: 2441/ 663  
PIXEL: 3345/ 232  
PIXEL: 3787/ 288  
PIXEL: 4403/ 637  
PIXEL: 4617/1234  
PIXEL: 5437/2885  
PIXEL: 5808/1693  
PIXEL: 254/3798  
PIXEL: 440/ 288  
PIXEL: 443/3956  
PIXEL: 559/3745  
PIXEL: 604/3700  
PIXEL: 846/3639  
PIXEL: 1309/3919  
PIXEL: 4264/3703  
PIXEL: 5460/1324  
PIXEL: 4968/3874  
PIXEL: 251/3960

## **C01-00**

PIXEL: 266/1347  
PIXEL: 410/ 281  
PIXEL: 1062/ 104  
PIXEL: 1117/1135  
PIXEL: 1589/ 913  
PIXEL: 2063/2144  
PIXEL: 2533/1627  
PIXEL: 2674/2684  
PIXEL: 3000/3731  
PIXEL: 3087/ 135



PIXEL: 3183/3399  
PIXEL: 3812/1793  
PIXEL: 4326/ 40  
PIXEL: 4383/1238  
PIXEL: 4404/2354  
PIXEL: 4472/3555  
PIXEL: 4693/1725  
PIXEL: 5150/ 373  
PIXEL: 5225/ 895  
PIXEL: 5448/2546  
PIXEL: 5525/1065  
PIXEL: 5819/3855  
PIXEL: 5861/3504  
PIXEL: 345/3992  
PIXEL: 182/3938

## **C01-01**

PIXEL: 190/1155  
PIXEL: 450/ 713  
PIXEL: 590/1200  
PIXEL: 677/3066  
PIXEL: 3371/2195  
PIXEL: 3708/ 447  
PIXEL: 3993/ 834  
PIXEL: 4234/ 954  
PIXEL: 5363/ 663  
PIXEL: 5439/3426

## **C02-00**

PIXEL: 160/2713  
PIXEL: 411/ 975  
PIXEL: 707/3483  
PIXEL: 972/2213  
PIXEL: 1240/3899  
PIXEL: 1755/1263  
PIXEL: 1955/2416  
PIXEL: 2306/3779  
PIXEL: 2470/2235  
PIXEL: 2587/3970  
PIXEL: 4025/1291  
PIXEL: 4075/2419  
PIXEL: 4141/2810  
PIXEL: 4155/3062  
PIXEL: 4285/1877  
PIXEL: 4512/1915  
PIXEL: 4824/2277  
PIXEL: 5089/3330  
PIXEL: 5354/1830  
PIXEL: 5489/ 271  
PIXEL: 5509/1097



PIXEL: 5779/ 659  
PIXEL: 5783/ 322  
PIXEL: 5785/ 207  
PIXEL: 5969/3651  
PIXEL: 4002/ 369

## **C02-01**

PIXEL: 95/ 369  
PIXEL: 157/ 127  
PIXEL: 189/1735  
PIXEL: 191/3444  
PIXEL: 1116/1760  
PIXEL: 1317/3959  
PIXEL: 1420/3336  
PIXEL: 1718/2011  
PIXEL: 1779/3739  
PIXEL: 3151/1045  
PIXEL: 3153/ 118  
PIXEL: 5395/ 322  
PIXEL: 5993/1180  
PIXEL: 2294/1125  
PIXEL: 3092/2944  
PIXEL: 3652/ 410  
PIXEL: 4872/2840

## **C03-00**

PIXEL: 735/2116  
PIXEL: 820/1257  
PIXEL: 1665/2735  
PIXEL: 2901/1146  
PIXEL: 3138/ 552  
PIXEL: 3471/3133  
PIXEL: 3513/3168  
PIXEL: 3588/ 533  
PIXEL: 4606/1977  
PIXEL: 4841/1588  
PIXEL: 4850/2982  
PIXEL: 5222/ 471  
PIXEL: 5437/ 670  
PIXEL: 5959/1688  
PIXEL: 542/1798  
PIXEL: 542/1799  
PIXEL: 894/ 207  
PIXEL: 895/ 207  
PIXEL: 3166/1259

## **C04-00**

PIXEL: 1123/3756  
PIXEL: 1126/3755  
PIXEL: 2303/3882



PIXEL: 2355/3418  
PIXEL: 2497/2984  
PIXEL: 5972/1054  
PIXEL: 853/ 33  
PIXEL: 4856/1050  
PIXEL: 4856/1051  
PIXEL: 4857/1050  
PIXEL: 4857/1051  
PIXEL: 4858/1050  
PIXEL: 5043/2852  
PIXEL: 5044/2852  
PIXEL: 5044/2853

## **C05-00**

PIXEL: 218/ 742  
PIXEL: 248/3728  
PIXEL: 2002/3388  
PIXEL: 2115/1373  
PIXEL: 2259/2731  
PIXEL: 2526/2575  
PIXEL: 2713/2903  
PIXEL: 3702/ 673  
PIXEL: 4757/ 128  
PIXEL: 5320/1148  
PIXEL: 5669/2751

## **C06-00**

PIXEL: 220/3080  
PIXEL: 322/ 182  
PIXEL: 569/ 69  
PIXEL: 1046/ 892  
PIXEL: 1450/3189  
PIXEL: 1663/1032  
PIXEL: 2017/3236  
PIXEL: 2035/1681  
PIXEL: 2228/3078  
PIXEL: 3095/1266  
PIXEL: 3615/2287  
PIXEL: 3920/1791  
PIXEL: 4030/ 884  
PIXEL: 4346/3312  
PIXEL: 5363/ 298  
PIXEL: 5726/ 450  
PIXEL: 5772/ 159  
PIXEL: 4941/2523

## **C07-00**

PIXEL: 866/ 155  
PIXEL: 1688/1457  
PIXEL: 3092/ 952





PIXEL: 3120/2311  
PIXEL: 4819/ 754  
PIXEL: 5012/2093  
PIXEL: 2667/3749

## **Notes**

COLUMN anomaly: all pixels below the Qmax detector at location (X,Y) may be affected.

PIXEL anomaly: single detector at location (X,Y) is not functioning within normal range

The Level0 coordinates exclude the two leftmost pixels containing the line index: the corresponding pixel can therefore be located at column (X+2,Y).



## Explanations

### Calibration Method:

The radiometric calibration is based on a series of 50 flat field images for each aperture size and sensor. The flat field is illuminated by eight normal light lamps with known spectral illumination curves.

These images are used to calculate the specific sensitivity of each pixel to compensate local as well as global variations in sensitivity. Sensitivity tables are calculated for each sensor and aperture setting, and applied during post processing from level 0 to level 1.

Outlier Pixels that do not have a linear behavior as described in the CCD specifications are marked as defective during the calibration procedure. These pixels are not used or only partially used during post processing and the information is restored by interpolation between the neighborhood pixels surrounding the defective pixels.

Certain pixels that are named Qmax pixels due to the fact that they can only store and transfer charge up to a certain maximum amount are detected in an additional calibration step. These pixels are treated differently during post processing, since their behavior can affect not only single pixel values but whole columns.



# ULTRACAM

## Shutter Calibration

---

**Camera:** UltraCam Falcon Prime  
**Serial:** UC-Fp-1-20519084-f100

**Panchromatic Camera:** 4 \* Prontor Magnetic 0  
Prontor-Werk Alfred Gauthier GmbH, Germany  
**Multispectral Camera:** 4 \* Prontor Magnetic 0  
Prontor-Werk Alfred Gauthier GmbH, Germany

**Calibration Date:** Mar-10-2017  
**Calibration Date:** Mar-14-2017  
**Camera Revision:** Rev03.00  
**Version of Report:** V01



## Calibration of Shutter Release Times:

The shutter release times measured during the calibration describe the time from the moment when the electrical current through the shutter is turned off by the electronics, until the shutter is mechanically closed.

This time is relevant for the exposure control and needs to be known before image recording can take place.

| Cone Number | Lens Serial Number | SRT F5.6 [ms] | SRT F6.7 [ms] | SRT F8 [ms] | SRT F9.5 [ms] | SRT F11 [ms] | SRT F13 [ms] | SRT F16 [ms] | SRT F22 [ms] | Measurement Tolerance [ms] |
|-------------|--------------------|---------------|---------------|-------------|---------------|--------------|--------------|--------------|--------------|----------------------------|
| C0 (Pan)    | 12 13 49 35        | 10.16         | 10.68         | 11.20       | 11.74         | 11.83        | 12.13        | 12.29        | 13.00        | +/- 0.2                    |
| C1 (Pan)    | 12 13 00 84        | 10.42         | 10.77         | 11.33       | 11.74         | 12.11        | 12.40        | 12.71        | 13.06        | +/- 0.2                    |
| C2 (Pan)    | 12 13 00 79        | 10.70         | 11.12         | 11.77       | 12.15         | 12.49        | 12.68        | 12.87        | 13.29        | +/- 0.2                    |
| C3 (Pan)    | 12 13 00 86        | 9.27          | 9.78          | 10.29       | 10.66         | 10.96        | 11.13        | 11.32        | 11.72        | +/- 0.2                    |
| C4 (Red)    | 12 13 00 96        | 11.45         | 11.73         | 11.99       | 12.22         | 12.40        | 12.52        | 12.60        | 12.96        | +/- 0.2                    |
| C5 (Green)  | 12 13 00 91        | 10.62         | 10.91         | 11.16       | 11.47         | 11.61        | 11.76        | 11.91        | 12.14        | +/- 0.2                    |
| C6 (Blue)   | 12 13 00 94        | 10.21         | 10.21         | 10.55       | 10.85         | 11.10        | 11.35        | 11.51        | 11.78        | +/- 0.2                    |
| C7 (NIR)    | 12 13 00 93        | 10.68         | 10.97         | 11.21       | 11.38         | 11.51        | 11.70        | 11.88        | 11.97        | +/- 0.2                    |





# ULTRACAM

## Electronics and Sensor Calibration

---

**Camera:** UltraCam Falcon Prime  
**Serial:** UC-Fp-1-20519084-f100

**Panchromatic Camera:** 9 \* FTF6040-M Area CCD Sensor by DALSA  
**Multispectral Camera:** 4 \* FTF6040-M Area CCD Sensor by DALSA

**Calibration Date:** Mar-10-2017  
**Calibration Date:** Mar-14-2017  
**Camera Revision:** Rev03.00  
**Version of Report:** V01



## Calibration of Negative Substrate Voltage (VNS):

For optimum performance of the DALSA CCD sensors, the negative substrate voltage is adjusted to a value specified by DALSA.

This voltage value is measured to achieve the best anti-blooming performance possible for each particular sensor.

| Cone_Sensor   | Sensor Type | Sensor Serial Number | VNS Voltage [V] |
|---------------|-------------|----------------------|-----------------|
| 00_00         | FTF6040-M   | 14 3859/056          | 22.50           |
| 00_01         | FTF6040-M   | 14 3859/053          | 22.80           |
| 00_02         | FTF6040-M   | 14 3859/046          | 22.60           |
| 00_03         | FTF6040-M   | 14 3859/051          | 22.60           |
| 01_00         | FTF6040-M   | 14 3859/043          | 22.60           |
| 01_01         | FTF6040-M   | 14 3859/042          | 22.60           |
| 02_00         | FTF6040-M   | 14 3859/006          | 22.60           |
| 02_01         | FTF6040-M   | 14 3859/014          | 22.50           |
| 03_00         | FTF6040-M   | 14 4982/023          | 22.50           |
| 04_00 (red)   | FTF6040-M   | 14 3859/058          | 22.50           |
| 05_00 (green) | FTF6040-M   | 14 892/058           | 22.30           |
| 06_00 (blue)  | FTF6040-M   | 14 2892/061          | 22.30           |
| 07_00 (NIR)   | FTF6040-M   | 14 2892/057          | 22.10           |



## Calibration of Intensity Threshold for Exposure Control:

Each CCD sensor and electronics module varies slightly in global sensitivity and intensity scale.

Therefore the maximum possible intensity of each sensor needs to be measured to evaluate the sensitivity behavior of the CCD and electronics.

This value is used as a threshold for the exposure control dialogue shown in the in-flight user interface of the Eagle.

| Cone_Sensor   | Sensor Type | Sensor Serial Number | Intensity Threshold [DN] |
|---------------|-------------|----------------------|--------------------------|
| 00_00         | FTF6040-M   | 14 3859/056          | 14010                    |
| 00_01         | FTF6040-M   | 14 3859/053          | 13480                    |
| 00_02         | FTF6040-M   | 14 3859/046          | 13780                    |
| 00_03         | FTF6040-M   | 14 3859/051          | 13410                    |
| 01_00         | FTF6040-M   | 14 3859/043          | 13980                    |
| 01_01         | FTF6040-M   | 14 3859/042          | 13860                    |
| 02_00         | FTF6040-M   | 14 3859/006          | 13990                    |
| 02_01         | FTF6040-M   | 14 3859/014          | 13390                    |
| 03_00         | FTF6040-M   | 14 4982/023          | 13260                    |
| 04_00 (red)   | FTF6040-M   | 14 3859/058          | 14050                    |
| 05_00 (green) | FTF6040-M   | 14 892/058           | 13630                    |
| 06_00 (blue)  | FTF6040-M   | 14 2892/061          | 13400                    |
| 07_00 (NIR)   | FTF6040-M   | 14 2892/057          | 13800                    |



# ULTRACAM

## Summary

---

|                           |                              |
|---------------------------|------------------------------|
| <b>Camera:</b>            | <b>UltraCam Falcon Prime</b> |
| <b>Serial:</b>            | <b>UC-Fp-1-20519084-f100</b> |
| <b>Calibration Date:</b>  | <b>Mar-10-2017</b>           |
| <b>Calibration Date:</b>  | <b>Mar-14-2017</b>           |
| <b>Camera Revision:</b>   | <b>Rev03.00</b>              |
| <b>Version of Report:</b> | <b>V01</b>                   |

The following calibrations have been performed for the above mentioned digital aerial mapping camera:

- Geometric Calibration
- Radiometric Calibration
- Shutter Calibration
- Sensor and Electronics Calibration

This equipment is operating fully within specification as defined by Vexcel Imaging GmbH.

Dr. Michael Gruber  
Chief Scientist, Photogrammetry  
Vexcel Imaging GmbH

Dipl. Ing. (FH) Helmut Jauk  
Senior Project Engineer R&D  
Vexcel Imaging GmbH