

Calibration Report



Camera:	UltraCam Eagle, S/N UC-Eagle-1-50319383-f80
Manufacturer:	Vexcel Imaging GmbH, A-8010 Graz, Austria
Date of Calibration:	Jan-14-2016
Date of Report:	Jan-28-2016
Revision of Camera:	Rev03
Version of Report:	V01

Calibration Report

Geometric Calibration



Camera:	UltraCam Eagle, S/N UC-Eagle-1-50319383-f80
Manufacturer:	Vexcel Imaging GmbH, A-8010 Graz, Austria
Panchromatic Camera:	ck = 79.800 mm
Multispectral Camera:	ck = 79.800 mm
Date of Calibration:	Jan-14-2016
Date of Report:	Jan-28-2016
Revision of Camera:	Rev03
Version of Report:	V01

Panchromatic Camera

Large Format Panchromatic Output Image

Image Format	long track	68.016mm	13080pixel
	cross track	104.052mm	20010pixel
Image Extent		(-34.01, -52.02)mm	(34.01, 52.02)mm
Pixel Size		5.200µm*5.200µm	
Focal Length	ck	79.800 mm	± 0.002mm
Principal Point (Level 2)	X_ppa	0.000 mm	± 0.002mm
	Y_ppa	0.000 mm	± 0.002mm
Lens Distortion	Remaining Distortion less than 0.002mm		

Multispectral Camera

Medium Format Multispectral Output Image (Upscaled to panchromatic image format)


Image Format	long track	68.016mm	4360pixel
	cross track	104.052mm	6670pixel
Image Extent		(-34.01, -52.02)mm	(34.01, 52.02)mm
Pixel Size		15.600µm*15.600µm	
Focal Length	ck	79.800 mm	
Principal Point (Level 2)	X_ppa	0.000 mm	± 0.002mm
	Y_ppa	0.000 mm	± 0.002mm
Lens Distortion	Remaining Distortion less than 0.002mm		

Individual Panchromatic Cone Data

Cone 0, Parametric Description, Not Effective in Output Image

Cone # C0													
Lens				Linor Vexcel Apo-Sironar Digital HR 1:5,6/80mm Linor GmbH, Germany									
Shutter				Prontor Magnetic Prontor-Werk Alfred Gauthier GmbH									
Image Extent (nominally)				(-34.28, -52.22)mm					(34.28, 52.22)mm				
Extent CCD 0				(-34.28, -52.22)mm					(-10.32, -16.28)mm				
Extent CCD 1				(-34.28, 16.28)mm					(-10.32, 52.22)mm				
Extent CCD 2				(10.32, -52.22)mm					(34.28, -16.28)mm				
Extent CCD 3				(10.32, 16.28)mm					(34.28, 52.22)mm				
Parameters			Shift X			ShiftY			Rotation			Scale	
CCD0			5.0077717E-02mm ± 0.0004 mm			1.0382278E-01mm ± 0.0007 mm			-3.2561877E-02gon ± 0.0001 gon			1.0043834 ± 0.00005	
CCD1			-1.6117846E-02mm ± 0.0004 mm			-1.2046403E-03mm ± 0.0007 mm			0.0000000E+00gon ± 0.0001 gon			1.0044253 ± 0.00005	
CCD2			-3.4254117E-02mm ± 0.0004 mm			5.5875993E-02mm ± 0.0007 mm			-5.1022120E-02gon ± 0.0001 gon			1.0042695 ± 0.00005	
CCD3			-8.4437277E-02mm ± 0.0004 mm			-4.6322900E-02mm ± 0.0007 mm			-7.2271638E-02gon ± 0.0001 gon			1.0038366 ± 0.00005	
Radial Distortion													
R [mm]	5.0	10.0	15.0	20.0	25.0	30.0	35.0	40.0	45.0	50.0	55.0	60.0	65.0
dr [µm]	35.1	66.4	96.3	124.8	149.4	164.8	163.7	135.9	68.9	-52.3	-245.1	-529.6	-928.2

Cone 0, Residual Error Diagram




Residual Error (RMS): **0.66 μm**

Cone 1, Parametric Description, Not Effective in Output Image

Cone # C1													
Lens			Linios Vexcel Apo-Sironar Digital HR 1:5,6/80mm Linios GmbH, Germany										
Shutter			Prontor Magnetic Prontor-Werk Alfred Gauthier GmbH										
Image Extent (nominally)			(-34.28, -17.97)mm					(34.28, 17.97)mm					
Extent CCD 0			(-34.28, -17.97)mm					(-10.42, 17.97)mm					
Extent CCD 1			(10.42, -17.97)mm					(34.28, 17.97)mm					
Parameters			Shift X			Shift Y			Rotation			Scale	
CCD0			-1.0940154E-02mm ± 0.0006 mm			3.1691855E-02mm ± 0.0005 mm			0.0000000E+00gon ± 0.0001 gon			1.0041352 ± 0.00005	
CCD1			-5.0943463E-02mm ± 0.0006 mm			8.2136307E-05mm ± 0.0005 mm			5.1376314E-02gon ± 0.0001 gon			1.0039358 ± 0.00005	
Radial Distortion													
R [mm]	5.0	10.0	15.0	20.0	25.0	30.0	35.0	40.0	45.0	50.0	55.0	60.0	
dr [µm]	12.6	24.2	35.7	46.4	53	50.2	30.5	-15.6	-100	-236.6	-441.5	-733	

UltraCamEagle, Serial Number UC-Eagle-1-50319383-f80

Cone 1, Residual Error Diagram




Residual Error (RMS): **0.50 μm**

Cone 2, Parametric Description, Not Effective in Output Image

Cone # C2												
Lens				Linios Vexcel Apo-Sironar Digital HR 1:5,6/80mm Linios GmbH, Germany								
Shutter				Prontor Magnetic Prontor-Werk Alfred Gauthier GmbH								
Image Extent (nominally)				(-11.98, -52.22)mm				(11.98, 52.22)mm				
Extent CCD 0				(-11.98, -52.22)mm				(11.98, -16.28)mm				
Extent CCD 1				(-11.98, 16.28)mm				(11.98, 52.22)mm				
Parameters		Shift X			ShiftY			Rotation			Scale	
CCD0		-2.0951968E-02mm ± 0.0004 mm			1.9492393E-02mm ± 0.0016 mm			3.7992489E-02gon ± 0.0001 gon			1.0061044 ± 0.00005	
CCD1		3.7681114E-02mm ± 0.0004 mm			5.1122635E-02mm ± 0.0016 mm			0.0000000E+00gon ± 0.0001 gon			1.0060939 ± 0.00005	
Radial Distortion												
R [mm]	5.0	10.0	15.0	20.0	25.0	30.0	35.0	40.0	45.0	50.0	55.0	60.0
dr [µm]	34.2	65.9	97	127.1	153.3	170.5	171.2	145.2	80.4	-38.1	-227.4	-506.8

UltraCamEagle, Serial Number UC-Eagle-1-50319383-f80

Cone 2, Residual Error Diagram




Residual Error (RMS): **0.57 μm**

Cone 3, Parametric Description, Not Effective in Output Image


Cone # C3					
Lens		Linios Vexcel Apo-Sironar Digital HR 1:5,6/80mm Linios GmbH, Germany			
Shutter		Prontor Magnetic Prontor-Werk Alfred Gauthier GmbH			
Image Extent (nominally)		(-11.98, -17.97)mm		(11.98, 17.97)mm	
Extent CCD 0		(-11.98, -17.97)mm		(11.98 , 17.97)mm	
Parameters		Shift X	ShiftY	Rotation	Scale
CCD0		5.5036478E-02mm ± 0.0008 mm	2.3262935E-02mm ± 0.0021 mm	0.0000000E+00gon ± 0.0001 gon	0.9998480 ± 0.00005
Radial Distortion					
R [mm]	5.0	10.0	15.0	20.0	25.0
dr [µm]	-2	-2.9	-3.6	-4	-4.3

Cone 3, Residual Error Diagram



Residual Error (RMS): **0.43 μm**

Full Pan Image, Residual Error Diagram



Residual Error (RMS): **0.55 μm**


Individual Multispectral Cone Data

Cone 4, Parametric Description, Not Effective in Output Image

Cone # C4 (red)											
Lens		Linios Vexcel HR Digaron 1:4/27mm Linios GmbH, Germany									
Shutter		Prontor Magnetic Prontor-Werk Alfred Gauthier GmbH									
Image Extent (nominally)		(-11.98, -17.97)mm		(11.98, 17.97)mm							
Extent CCD 0		(-11.98, -17.97)mm		(11.98 , 17.97)mm							
Parameters		Shift X		ShiftY		Rotation		Scale			
CCD0		-6.4147438E-02mm ± 0.0000 mm		-4.6550349E-02mm ± 0.0001 mm		0.0000000E+00gon ± 0.0001 gon		1.0551183 ± 0.00005			
Radial Distortion											
R [mm]		5.0		10.0		15.0		20.0		25.0	
dr [µm]		117.5		158.4		181		183.9		169.1	

UltraCamEagle, Serial Number UC-Eagle-1-50319383-f80

Cone 4, Residual Error Diagram




Residual Error (RMS): **0.49 μm**

Cone 5, Parametric Description, Not Effective in Output Image

Cone # C5 (green)					
Lens		Linios Vexcel HR Digaron 1:4/27mm Linios GmbH, Germany			
Shutter		Prontor Magnetic Prontor-Werk Alfred Gauthier GmbH			
Image Extent (nominally)		(-11.98, -17.97)mm		(11.98, 17.97)mm	
Extent CCD 0		(-11.98, -17.97)mm		(11.98 , 17.97)mm	
Parameters		Shift X	Shift Y	Rotation	Scale
CCD0	-6.9436138E-03mm ± 0.0000 mm	-6.8576738E-02mm ± 0.0001 mm	0.0000000E+00gon ± 0.0001 gon	1.0534565 ± 0.00005	
Radial Distortion					
R [mm]	5.0	10.0	15.0	20.0	25.0
dr [µm]	115.8	155.7	177.5	180.2	165.9

Cone 5, Residual Error Diagram




Residual Error (RMS): **0.50 μm**

Cone 6, Parametric Description, Not Effective in Output Image

Cone # C6 (blue)					
Lens		Linor Vexcel HR Digaron 1:4/27mm Linor GmbH, Germany			
Shutter		Prontor Magnetic Prontor-Werk Alfred Gauthier GmbH			
Image Extent (nominally)		(-11.98, -17.97)mm		(11.98, 17.97)mm	
Extent CCD 0		(-11.98, -17.97)mm		(11.98 , 17.97)mm	
Parameters		Shift X	ShiftY	Rotation	Scale
CCD0		-3.1463194E-02mm ± 0.0000 mm	-1.5696244E-02mm ± 0.0001 mm	0.0000000E+00gon ± 0.0001 gon	1.0539814 ± 0.00005
Radial Distortion					
R [mm]	5.0	10.0	15.0	20.0	25.0
dr [µm]	115	155.1	177.1	180.1	165.9

UltraCamEagle, Serial Number UC-Eagle-1-50319383-f80

Cone 6, Residual Error Diagram




Residual Error (RMS): 0.49 μm

Cone 7, Parametric Description, Not Effective in Output Image

Cone # C7 (NIR)					
Lens		Linos Vexcel HR Digaron 1:4/27mm Linos GmbH, Germany			
Shutter		Prontor Magnetic Prontor-Werk Alfred Gauthier GmbH			
Image Extent (nominally)		(-11.98, -17.97)mm		(11.98, 17.97)mm	
Extent CCD 0		(-11.98, -17.97)mm		(11.98 , 17.97)mm	
Parameters		Shift X	ShiftY	Rotation	Scale
CCD0		2.6959715E-02mm ± 0.0000 mm	-4.0481015E-02mm ± 0.0001 mm	0.0000000E+00gon ± 0.0001 gon	1.0563754 ± 0.00005
Radial Distortion					
R [mm]	5.0	10.0	15.0	20.0	25.0
dr [µm]	116.8	157.4	179.8	182.8	168.6

UltraCamEagle, Serial Number UC-Eagle-1-50319383-f80

Cone 7, Residual Error Diagram



Residual Error (RMS): 0.50 μm

Explanations:

1) Calibration Method:


The geometric calibration is based on a set of 84 images of a defined geometry target with 394 GCPs.

Number of point measurements for the panchromatic camera : 19482
 Number of point measurements for the multispectral camera : 77958

Determination of the image parameters by Least Squares Adjustment.
 Software used for the adjustment: BINGO (GIP Eng. Aalen, Germany)

2) Level 2 Image Coordinate System: PAN 20010 pixel by 13080 pixel
 MS 6670 pixel by 4360 pixel


Lvl2, Camera prop. Orientation




The image coordinate system of the Level 2 images is shown in the above figure. The level 2 image consists of 20010 columns and 13080 rows, which leads to a total image format of 104.052 x 68.016 mm. The coordinate of the principal point in the level 2 image is given on page 3 of this report. The above figure shows the position of an example principal point at the coordinate (-0.123 / 0.345).

3) Level 3 Image Coordinate System:
(after rotation of 270° CW)

PAN 20010 pixel by 13080 pixel
MS 6670 pixel by 4360 pixel



Panchromatic Image Format



Multispectral Image Format


4) Position of Principal Point in Level 3 Image

The position of the principal point in the level 3 image depends on the “rotation” setting used in UltraMap during the pan-sharpening step. The exact position relative to the image center is given in the table below as a function of the rotation setting used in UltraMap. The coordinates are specified for clockwise (CW) rotation in steps of 90 degrees, according to the principal point coordinate given on page 3 for high- and low resolution images.


Image Format	Clockwise Rotation (Degree)	PPA	
		X	Y
Level 2	-	0.000	0.000
Level 3	0	0.000	0.000
Level 3	90	0.000	0.000
Level 3	180	0.000	0.000
Level 3	270	0.000	0.000

The coordinates in the figure below are only example values to illustrate the effect of image rotation on the principal point position, and do **not** correspond to the camera described in this report.


Lvl3, Rotation 0 deg clockwise




Lvl3, Rotation 90 deg clockwise



Lvl3, Rotation 270 deg clockwise



Lvl3, Rotation 180 deg clockwise




Lens Resolving Power

The following curves show the development of the modulation transfer function across different image heights of the panchromatic cones. Please note that these values have been calculated and can vary up to 10% with optics from production (especially at high LP's).


The curves are given for the meridional (tangential) and sagital (radial) component of signals at frequencies of 12.5, 25, 50 and 100 line pairs per millimeter.

As the MTF is a function of the specific aperture size used, one set of curves is given for each aperture size.


Modulation versus Image Height - Aperture f / 5.6




Modulation versus Image Height - Aperture f / 6.7





Modulation versus Image Height - Aperture f / 8



Modulation versus Image Height - Aperture f / 9.5



Spectral Sensitivity



Calibration Report

Radiometric Calibration



Camera: UltraCam Eagle, S/N UC-Eagle-1-50319383-f80

Manufacturer: Vexcel Imaging GmbH, A-8010 Graz,
Austria

	PAN	R, G, NIR	B
Aperture	F5.6	F8.0	F5.6
	F6.7	F9.3	F6.5
	F8	F11	F8
	F9.5	F13	F9.5
	F11	F16	F11
	F13	F19	F13
	F16	F22	F16
	F22	F27	F22

Date of Calibration: Jan-14-2016
Date of Report: Jan-28-2016
Revision of Camera: Rev03
Version of Report: V01

Calibration of Vignetting for Aperture Setting 1


	PAN	R, G, NIR	B
Aperture	F5.6	F8.0	F5.6

Overview of Individual Sensor Gain Values:

Cone_Sensor	Aperture	Minimum Gain \geq	Maximum Gain \leq
00_00	f / 5.6	1.00	4.00
00_01	f / 5.6	1.00	4.00
00_02	f / 5.6	1.00	4.00
00_03	f / 5.6	1.00	4.00
01_00	f / 5.6	1.00	2.00
01_01	f / 5.6	1.00	2.00
02_00	f / 5.6	1.00	3.00
02_01	f / 5.6	1.00	3.00
03_00	f / 5.6	1.00	2.00
04_00 (red)	f / 8	1.00	5.00
05_00 (green)	f / 8	1.00	3.00
06_00 (blue)	f / 5.6	1.00	3.00
07_00 (NIR)	f / 8	1.00	4.00

Calibration of Vignetting for Aperture Setting 1

Graphical Overview of Pan Sensor Gain Values:



Graphical Overview of Multispectral Sensor Gain Values:



Calibration of Vignetting for Aperture Setting 2


	PAN	R, G, NIR	B
Aperture	F6.7	F9.3	F6.7

Overview of Individual Sensor Gain Values:

Cone_Sensor	Aperture	Minimum Gain \geq	Maximum Gain \leq
00_00	f / 6.5	1.00	4.00
00_01	f / 6.5	1.00	3.00
00_02	f / 6.5	1.00	4.00
00_03	f / 6.5	1.00	3.00
01_00	f / 6.5	1.00	2.00
01_01	f / 6.5	1.00	2.00
02_00	f / 6.5	1.00	3.00
02_01	f / 6.5	1.00	3.00
03_00	f / 6.5	1.00	2.00
04_00 (red)	f / 9.3	1.00	5.00
05_00 (green)	f / 9.3	1.00	3.00
06_00 (blue)	f / 6.5	1.00	3.00
07_00 (NIR)	f / 9.3	1.00	4.00

Calibration of Vignetting for Aperture Setting 2

Graphical Overview of Pan Sensor Gain Values:

Graphical Overview of Multispectral Sensor Gain Values:

Calibration of Vignetting for Aperture Setting 3










	PAN	R, G, NIR	B
Aperture	F8	F11	F8

Overview of Individual Sensor Gain Values:

Cone_Sensor	Aperture	Minimum Gain \geq	Maximum Gain \leq
00_00	f / 8	1.00	3.00
00_01	f / 8	1.00	3.00
00_02	f / 8	1.00	4.00
00_03	f / 8	1.00	3.00
01_00	f / 8	1.00	2.00
01_01	f / 8	1.00	2.00
02_00	f / 8	1.00	3.00
02_01	f / 8	1.00	3.00
03_00	f / 8	1.00	2.00
04_00 (red)	f / 11	1.00	4.00
05_00 (green)	f / 11	1.00	3.00
06_00 (blue)	f / 8	1.00	3.00
07_00 (NIR)	f / 11	1.00	3.00

Calibration of Vignetting for Aperture Setting 3

Graphical Overview of Pan Sensor Gain Values:

Graphical Overview of Multispectral Sensor Gain Values:

Calibration of Vignetting for Aperture Setting 4


	PAN	R, G, NIR	B
Aperture	F9.5	F13	F9.5

Overview of Individual Sensor Gain Values:

Cone_Sensor	Aperture	Minimum Gain \geq	Maximum Gain \leq
00_00	f / 9.5	1.00	3.00
00_01	f / 9.5	1.00	3.00
00_02	f / 9.5	1.00	4.00
00_03	f / 9.5	1.00	3.00
01_00	f / 9.5	1.00	2.00
01_01	f / 9.5	1.00	2.00
02_00	f / 9.5	1.00	3.00
02_01	f / 9.5	1.00	3.00
03_00	f / 9.5	1.00	2.00
04_00 (red)	f / 13	1.00	4.00
05_00 (green)	f / 13	1.00	3.00
06_00 (blue)	f / 9.5	1.00	3.00
07_00 (NIR)	f / 13	1.00	3.00

Calibration of Vignetting for Aperture Setting 4

Graphical Overview of Pan Sensor Gain Values:



Graphical Overview of Multispectral Sensor Gain Values:



Calibration of Vignetting for Aperture Setting 5


	PAN	R, G, NIR	B
Aperture	F11	F16	F11

Overview of Individual Sensor Gain Values:

Cone_Sensor	Aperture	Minimum Gain \geq	Maximum Gain \leq
00_00	f / 11	1.00	3.00
00_01	f / 11	1.00	3.00
00_02	f / 11	1.00	4.00
00_03	f / 11	1.00	3.00
01_00	f / 11	1.00	2.00
01_01	f / 11	1.00	2.00
02_00	f / 11	1.00	3.00
02_01	f / 11	1.00	3.00
03_00	f / 11	1.00	2.00
04_00 (red)	f / 16	1.00	4.00
05_00 (green)	f / 16	1.00	3.00
06_00 (blue)	f / 11	1.00	3.00
07_00 (NIR)	f / 16	1.00	3.00

Calibration of Vignetting for Aperture Setting 5

Graphical Overview of Pan Sensor Gain Values:



Graphical Overview of Multispectral Sensor Gain Values:



Calibration of Vignetting for Aperture Setting 6


	PAN	R, G, NIR	B
Aperture	F13	F19	F13

Overview of Individual Sensor Gain Values:

Cone_Sensor	Aperture	Minimum Gain \geq	Maximum Gain \leq
00_00	f / 13	1.00	3.00
00_01	f / 13	1.00	3.00
00_02	f / 13	1.00	4.00
00_03	f / 13	1.00	3.00
01_00	f / 13	1.00	2.00
01_01	f / 13	1.00	2.00
02_00	f / 13	1.00	3.00
02_01	f / 13	1.00	3.00
03_00	f / 13	1.00	2.00
04_00 (red)	f / 19	1.00	4.00
05_00 (green)	f / 19	1.00	3.00
06_00 (blue)	f / 13	1.00	3.00
07_00 (NIR)	f / 19	1.00	3.00

Calibration of Vignetting for Aperture Setting 6

Graphical Overview of Pan Sensor Gain Values:



Graphical Overview of Multispectral Sensor Gain Values:



Calibration of Vignetting for Aperture Setting 7










	PAN	R, G, NIR	B
Aperture	F16	F22	F16

Overview of Individual Sensor Gain Values:

Cone_Sensor	Aperture	Minimum Gain \geq	Maximum Gain \leq
00_00	f / 16	1.00	3.00
00_01	f / 16	1.00	3.00
00_02	f / 16	1.00	4.00
00_03	f / 16	1.00	3.00
01_00	f / 16	1.00	2.00
01_01	f / 16	1.00	2.00
02_00	f / 16	1.00	3.00
02_01	f / 16	1.00	3.00
03_00	f / 16	1.00	2.00
04_00 (red)	f / 22	1.00	4.00
05_00 (green)	f / 22	1.00	3.00
06_00 (blue)	f / 16	1.00	3.00
07_00 (NIR)	f / 22	1.00	3.00

Calibration of Vignetting for Aperture Setting 7

Graphical Overview of Pan Sensor Gain Values:

Graphical Overview of Multispectral Sensor Gain Values:

Calibration of Vignetting for Aperture Setting 8










	PAN	R, G, NIR	B
Aperture	F22	F27	F22

Overview of Individual Sensor Gain Values:

Cone_Sensor	Aperture	Minimum Gain \geq	Maximum Gain \leq
00_00	f / 22	1.00	3.00
00_01	f / 22	1.00	3.00
00_02	f / 22	1.00	4.00
00_03	f / 22	1.00	3.00
01_00	f / 22	1.00	2.00
01_01	f / 22	1.00	2.00
02_00	f / 22	1.00	3.00
02_01	f / 22	1.00	3.00
03_00	f / 22	1.00	2.00
04_00 (red)	f / 27	1.00	4.00
05_00 (green)	f / 27	1.00	3.00
06_00 (blue)	f / 22	1.00	3.00
07_00 (NIR)	f / 27	1.00	3.00

Calibration of Vignetting for Aperture Setting 8

Graphical Overview of Pan Sensor Gain Values:

00_00	01_00	00_01
02_00	03_00	02_01
00_02	01_01	00_03

Graphical Overview of Multispectral Sensor Gain Values:

04_00 (RED)	06_00 (BLUE)
05_00 (GREEN)	07_00 (NIR)

Defective Pixel Report:

Sensor		
Anomaly Type	X	Y

C00-00

PIXEL: 1318/3743
 PIXEL: 1414/1364
 PIXEL: 1695/ 738
 PIXEL: 1803/4197
 PIXEL: 2267/1263
 PIXEL: 2284/4400
 PIXEL: 2293/ 332
 PIXEL: 2360/1247
 PIXEL: 2569/3386
 PIXEL: 2617/ 666
 PIXEL: 3885/ 647
 PIXEL: 3909/3509
 PIXEL: 4141/3052
 PIXEL: 4417/3968
 PIXEL: 4851/1360
 PIXEL: 4905/2138
 PIXEL: 5059/2807
 PIXEL: 5976/ 728
 PIXEL: 6002/2188
 PIXEL: 6440/2783
 PIXEL: 4018/3892
 PIXEL: 4018/3893
 PIXEL: 4956/3705
 PIXEL: 4957/3705
 PIXEL: 4019/3892
 PIXEL: 4019/3893
 PIXEL: 4017/3892
 PIXEL: 4956/3704
 PIXEL: 3518/ 376
 PIXEL: 3519/ 376
 PIXEL: 1722/ 94
 PIXEL: 2192/ 33
 PIXEL: 63/ 18
 COLUMN: 6757/2039

C00-01

PIXEL: 109/3301
 PIXEL: 768/2165
 PIXEL: 815/2156
 PIXEL: 963/ 695
 PIXEL: 1312/ 790
 PIXEL: 2161/1326
 PIXEL: 2182/3165
 PIXEL: 2672/2623
 PIXEL: 2844/3451
 PIXEL: 3591/1391
 PIXEL: 4102/3119
 PIXEL: 4280/3677
 PIXEL: 4330/4255
 PIXEL: 4547/ 245

UltraCamEagle, Serial Number UC-Eagle-1-50319383-f80

PIXEL: 4858/2507
PIXEL: 5279/2419
PIXEL: 5392/3221
PIXEL: 5418/ 220
PIXEL: 5670/1008
PIXEL: 6539/2603
PIXEL: 4668/4571
PIXEL: 4669/4571
PIXEL: 4670/4571
PIXEL: 4670/4572
PIXEL: 4669/4572
PIXEL: 4669/4570
PIXEL: 4668/4570
PIXEL: 4668/4572

C00-02

PIXEL: 1096/ 195
PIXEL: 1097/ 195
PIXEL: 101/1003
PIXEL: 464/ 134
PIXEL: 1015/3652
PIXEL: 2373/4146
PIXEL: 2413/ 734
PIXEL: 3533/2337
PIXEL: 4333/ 991
PIXEL: 4392/1373
PIXEL: 5381/2243
PIXEL: 5549/3102
PIXEL: 6259/1898
PIXEL: 6949/1862
PIXEL: 1095/ 196
PIXEL: 1096/ 196
PIXEL: 1098/ 195
PIXEL: 6329/ 602
PIXEL: 4189/4613
PIXEL: 4189/4612
PIXEL: 4189/4611
PIXEL: 4189/4609
PIXEL: 4190/4610
PIXEL: 4191/4612
PIXEL: 4191/4613

C00-03

PIXEL: 329/2295
PIXEL: 588/2222
PIXEL: 1025/1805
PIXEL: 1716/3137
PIXEL: 1871/4184
PIXEL: 2524/ 872
PIXEL: 2579/4605
PIXEL: 2810/3399
PIXEL: 2861/ 435
PIXEL: 2868/ 787
PIXEL: 3238/4183
PIXEL: 3503/3719
PIXEL: 3630/3104
PIXEL: 3777/ 684
PIXEL: 3913/4053
PIXEL: 4006/2198
PIXEL: 4105/3026
PIXEL: 4179/3674
PIXEL: 4265/2934

UltraCamEagle, Serial Number UC-Eagle-1-50319383-f80

PIXEL: 4299/ 748
 PIXEL: 4413/2254
 PIXEL: 4557/1357
 PIXEL: 5429/1656
 PIXEL: 5661/4548
 PIXEL: 6495/4623
 PIXEL: 6653/ 455
 PIXEL: 1657/3399
 COLUMN: 4632/1246

C01-00

PIXEL: 256/1880
 PIXEL: 1453/4347
 PIXEL: 1889/4571
 PIXEL: 1931/4513
 PIXEL: 2354/4401
 PIXEL: 3231/1170
 PIXEL: 3335/3505
 PIXEL: 4143/2465
 PIXEL: 4204/4377
 PIXEL: 5571/ 226
 PIXEL: 5963/3754
 PIXEL: 6033/2785
 PIXEL: 63/4246
 PIXEL: 77/ 146
 PIXEL: 358/4249
 PIXEL: 792/ 811
 PIXEL: 829/ 806
 PIXEL: 2292/1180
 PIXEL: 2293/1179
 PIXEL: 2293/1180
 PIXEL: 3878/ 642
 PIXEL: 3878/ 643
 PIXEL: 5322/2473
 PIXEL: 357/4249
 PIXEL: 358/4248
 PIXEL: 2292/1179
 PIXEL: 2293/1178
 PIXEL: 3879/ 642
 PIXEL: 3879/ 643
 PIXEL: 5323/2473
 PIXEL: 5323/2472
 PIXEL: 5322/2472
 PIXEL: 4548/4616
 PIXEL: 4549/4616
 PIXEL: 4548/4617
 PIXEL: 4426/4594
 PIXEL: 3184/1763
 PIXEL: 117/1243
 PIXEL: 3237/ 32
 PIXEL: 3236/ 33
 PIXEL: 3236/ 32
 PIXEL: 3236/ 31

C01-01

PIXEL: 792/ 601
 PIXEL: 2537/1141
 PIXEL: 2773/3945
 PIXEL: 3713/4325
 PIXEL: 4044/4089
 PIXEL: 4224/ 918
 PIXEL: 5198/2887

UltraCamEagle, Serial Number UC-Eagle-1-50319383-f80

PIXEL: 5482/ 746
 PIXEL: 154/ 40
 PIXEL: 247/4265
 PIXEL: 247/4266
 PIXEL: 248/4265
 PIXEL: 248/4266
 PIXEL: 1799/1331
 PIXEL: 1800/1331
 PIXEL: 1801/1331
 PIXEL: 2413/1096
 PIXEL: 43/ 32
 PIXEL: 6799/ 364
 PIXEL: 6799/ 363
 PIXEL: 6797/ 363
 PIXEL: 6797/ 362
 PIXEL: 6799/ 362
 PIXEL: 291/4609
 PIXEL: 291/4608
 PIXEL: 292/4610
 PIXEL: 292/4609
 PIXEL: 204/4574
 PIXEL: 205/4574

C02-00

PIXEL: 336/2712
 PIXEL: 346/ 225
 PIXEL: 485/1811
 PIXEL: 2656/2560
 PIXEL: 2972/1959
 PIXEL: 4659/2662
 PIXEL: 5041/2934
 PIXEL: 5128/ 451
 PIXEL: 6067/3816
 PIXEL: 6084/1568
 PIXEL: 6113/2915
 PIXEL: 1594/1549
 PIXEL: 1595/1549
 PIXEL: 3158/ 707
 PIXEL: 3159/ 707
 PIXEL: 3158/ 708
 PIXEL: 4939/ 498
 PIXEL: 4941/ 500
 PIXEL: 4941/ 499
 PIXEL: 6929/1620
 PIXEL: 6928/1620
 PIXEL: 6929/1619

C02-01

PIXEL: 183/2167
 PIXEL: 673/4171
 PIXEL: 1544/1256
 PIXEL: 1766/2986
 PIXEL: 2677/1352
 PIXEL: 3510/ 842
 PIXEL: 3625/1933
 PIXEL: 3625/1934
 PIXEL: 3888/1764
 PIXEL: 4029/2247
 PIXEL: 4130/1229
 PIXEL: 4392/3718
 PIXEL: 5898/2481
 PIXEL: 6178/ 995

UltraCamEagle, Serial Number UC-Eagle-1-50319383-f80

PIXEL: 6808/1786
 PIXEL: 6934/3171
 PIXEL: 145/3292
 PIXEL: 3620/4353
 PIXEL: 4988/2042
 PIXEL: 4988/2043
 PIXEL: 1928/ 92
 PIXEL: 1929/ 93
 PIXEL: 1930/ 93
 PIXEL: 1930/ 94
 PIXEL: 1929/ 94
 PIXEL: 1928/ 93
 PIXEL: 237/ 89
 PIXEL: 4989/2043
 PIXEL: 2680/3465
 PIXEL: 3621/4353

C03-00

PIXEL: 61/ 321
 PIXEL: 398/1925
 PIXEL: 1248/ 598
 PIXEL: 1698/ 153
 PIXEL: 2651/ 241
 PIXEL: 2966/3691
 PIXEL: 3091/3603
 PIXEL: 3631/4106
 PIXEL: 4923/1826
 PIXEL: 4975/3230
 PIXEL: 5830/1961
 PIXEL: 6419/1235
 PIXEL: 6547/4303
 PIXEL: 6547/4304
 PIXEL: 6548/4304
 PIXEL: 6734/3883
 PIXEL: 513/ 81
 PIXEL: 514/ 81
 PIXEL: 515/ 81
 PIXEL: 516/ 81
 PIXEL: 512/ 81
 PIXEL: 891/ 93
 PIXEL: 892/ 93
 PIXEL: 215/ 282
 PIXEL: 215/ 281
 PIXEL: 214/ 281
 PIXEL: 216/ 281
 PIXEL: 216/ 282
 PIXEL: 214/ 282
 PIXEL: 2375/ 459
 PIXEL: 6087/4144
 PIXEL: 6086/4144
 PIXEL: 6087/4143
 PIXEL: 46/4590

C04-00

PIXEL: 547/1916
 PIXEL: 1606/3487
 PIXEL: 3624/2130
 PIXEL: 4642/1226
 PIXEL: 6695/2185
 PIXEL: 28/ 84

UltraCamEagle, Serial Number UC-Eagle-1-50319383-f80

C05-00

PIXEL: 481/ 463
PIXEL: 496/4250
PIXEL: 550/ 114
PIXEL: 2633/3025
PIXEL: 5070/2279
PIXEL: 5389/2146
PIXEL: 5917/4297
PIXEL: 6229/1855
PIXEL: 6642/1054
PIXEL: 2247/ 504
PIXEL: 6027/ 24
PIXEL: 1563/4208

C06-00

PIXEL: 565/4024
PIXEL: 389/3129
PIXEL: 475/4328
PIXEL: 595/ 806
PIXEL: 631/3351
PIXEL: 662/ 15
PIXEL: 1076/ 352
PIXEL: 1147/3181
PIXEL: 1585/3978
PIXEL: 1768/2974
PIXEL: 2043/4127
PIXEL: 2401/ 615
PIXEL: 3140/1384
PIXEL: 3159/2210
PIXEL: 3686/2795
PIXEL: 4187/ 805
PIXEL: 4637/1646
PIXEL: 4675/3160
PIXEL: 4827/2221
PIXEL: 4869/2678
PIXEL: 5199/1719
PIXEL: 5328/2995
PIXEL: 5380/2709
PIXEL: 5778/1849
PIXEL: 5908/3136
PIXEL: 6448/1813
PIXEL: 6656/3452
PIXEL: 6688/2208
PIXEL: 6773/3340
PIXEL: 565/4023
PIXEL: 4951/4043
PIXEL: 4951/4044
PIXEL: 4952/4044
PIXEL: 6699/ 198
PIXEL: 1076/ 353

C07-00

PIXEL: 1308/1694
PIXEL: 1557/4267
PIXEL: 1756/ 761
PIXEL: 2150/ 502
PIXEL: 2193/2235
PIXEL: 2626/2609
PIXEL: 3366/3708
PIXEL: 5567/3560
PIXEL: 6391/ 721

UltraCamEagle, Serial Number UC-Eagle-1-50319383-f80

PIXEL: 405/4430
PIXEL: 1234/ 46
PIXEL: 1234/ 47
PIXEL: 1235/ 49
PIXEL: 1236/ 45
PIXEL: 1236/ 46
PIXEL: 1235/ 46
PIXEL: 1476/2280
PIXEL: 2569/3386
PIXEL: 148/1312
PIXEL: 209/3986
PIXEL: 438/ 669
PIXEL: 466/ 681
PIXEL: 659/ 998
PIXEL: 695/ 353
PIXEL: 850/ 217
PIXEL: 2402/4014
PIXEL: 4018/3892
PIXEL: 4018/3893
PIXEL: 4956/3705
PIXEL: 4957/3705
PIXEL: 63/ 18
PIXEL: 2671/4576

Notes

COLUMN anomaly: all pixels below the Qmax detector at location (X,Y) may be affected.

PIXEL anomaly: single detector at location (X,Y) is not functioning within normal range

The Level0 coordinates exclude the two leftmost pixels containing the line index: the corresponding pixel can therefore be located at column (X+2,Y).

Explanations:

Calibration Method:

The radiometric calibration is based on a series of 50 flat field images for each aperture size and sensor. The flat field is illuminated by eight normal light lamps with known spectral illumination curves.

These images are used to calculate the specific sensitivity of each pixel to compensate local as well as global variations in sensitivity. Sensitivity tables are calculated for each sensor and aperture setting, and applied during post processing from level 0 to level 1.

Outlier Pixels that do not have a linear behavior as described in the CCD specifications are marked as defective during the calibration procedure. These pixels are not used or only partially used during post processing and the information is restored by interpolation between the neighborhood pixels surrounding the defective pixels.

Certain pixels that are named Qmax pixels due to the fact that they can only store and transfer charge up to a certain maximum amount are detected in an additional calibration step. These pixels are treated differently during post processing, since their behavior can affect not only single pixel values but whole columns.

Calibration Report

Shutter Calibration



Camera:	UltraCam Eagle, S/N UC-Eagle-1-50319383-f80
Manufacturer:	Vexcel Imaging GmbH, A-8010 Graz, Austria
Panchromatic Camera:	4 * Prontor Magnetic 0 Prontor-Werk Alfred Gauthier GmbH, Germany
Multispectral Camera:	4 * Prontor Magnetic 0 Prontor-Werk Alfred Gauthier GmbH, Germany
Date of Calibration:	Jan-14-2016
Date of Report:	Jan-28-2016
Revision of Camera:	Rev03
Version of Report:	V01

Calibration of Shutter Release Times:

The shutter release times measured during the calibration describe the time from the moment when the electrical current through the shutter is turned off by the electronics, until the shutter is mechanically closed.

This time is relevant for the exposure control and needs to be known before image recording can take place.

Cone Number	Lens Serial Number	SRT F5.6 [ms]	SRT F6.7 [ms]	SRT F8 [ms]	SRT F9.5 [ms]	SRT F11 [ms]	SRT F13 [ms]	SRT F16 [ms]	SRT F22 [ms]	Measurement Tolerance [ms]
C0 (Pan 4CCD)	12 15 42 95	11.26	11.61	12.09	12.41	12.7	12.99	13.23	13.69	+/- 0.2
C1 (Pan 2CCD V)	12 15 42 86	10.73	11.1	11.55	11.95	12.31	12.56	12.64	12.97	+/- 0.2
C2 (Pan 2CCD H)	12 15 43 00	11.55	11.93	12.55	12.83	13.32	13.67	13.85	13.95	+/- 0.2
C3 (Pan Central)	12 15 42 98	11.49	11.99	12.41	12.93	13.14	13.52	13.52	14.12	+/- 0.2
C4 (Red)	12 12 05 88	12.61	12.61	12.84	13.22	13.22	13.28	13.28	13.59	+/- 0.2
C5 (Green)	12 12 06 38	13.35	13.35	13.7	13.87	14.05	14.23	14.23	14.36	+/- 0.2
C6 (Blue)	12 12 06 30	12.25	12.4	12.4	12.59	12.77	13.13	13.13	13.48	+/- 0.2
C7 (NIR)	12 12 05 87	14	14.13	14.48	14.68	14.98	14.98	15.11	15.11	+/- 0.2

Calibration Report

Electronics and Sensor Calibration



Camera:	UltraCam Eagle, S/N UC-Eagle-1-50319383-f80
Manufacturer:	Vexcel Imaging GmbH, A-8010 Graz, Austria
Panchromatic Camera:	9 * FTF7046-M Area CCD Sensor by DALSA
Multispectral Camera:	4 * FTF7046-M Area CCD Sensor by DALSA
Date of Calibration:	Jan-14-2016
Date of Report:	Jan-28-2016
Revision of Camera:	Rev03
Version of Report:	V01

Calibration of Negative Substrate Voltage (VNS):

For optimum performance of the DALSA CCD sensors, the negative substrate voltage is adjusted to a value specified by DALSA.

This voltage value is measured to achieve the best anti-blooming performance possible for each particular sensor.

Cone_Sensor	Sensor Type	Sensor Serial Number	VNS Voltage [V]
00_00	FTF7046-M	15 1276/034	24.40
00_01	FTF7046-M	15 1276/035	24.20
00_02	FTF7046-M	15 1276/033	25.00
00_03	FTF7046-M	15 1276/032	24.20
01_00	FTF7046-M	14 9219/032	23.60
01_01	FTF7046-M	14 8779/045	24.40
02_00	FTF7046-M	14 9895/006	24.20
02_01	FTF7046-M	15 1276/023	23.40
03_00	FTF7046-M	15 0541/009	23.60
04_00 (red)	FTF7046-M	15 0541/037	23.60
05_00 (green)	FTF7046-M	15 0541/033	23.60
06_00 (blue)	FTF7046-M	15 7349/048	24.40
07_00 (NIR)	FTF7046-M	15 0541/031	23.40

Calibration of Intensity Threshold for Exposure Control:

Each CCD sensor and electronics module varies slightly in global sensitivity and intensity scale.

Therefore the maximum possible intensity of each sensor needs to be measured to evaluate the sensitivity behavior of the CCD and electronics.

This value is used as a threshold for the exposure control dialogue shown in the in-flight user interface of the Eagle.

Cone_Sensor	Sensor Type	Sensor Serial Number	Intensity Threshold [DN]
00_00	FTF7046-M	15 1276/034	13300
00_01	FTF7046-M	15 1276/035	13210
00_02	FTF7046-M	15 1276/033	13140
00_03	FTF7046-M	15 1276/032	13470
01_00	FTF7046-M	14 9219/032	13720
01_01	FTF7046-M	14 8779/045	13900
02_00	FTF7046-M	14 9895/006	13970
02_01	FTF7046-M	15 1276/023	14130
03_00	FTF7046-M	15 0541/009	13540
04_00 (red)	FTF7046-M	15 0541/037	13950
05_00 (green)	FTF7046-M	15 0541/033	13920
06_00 (blue)	FTF7046-M	15 7349/048	13620
07_00 (NIR)	FTF7046-M	15 0541/031	13290

Calibration Report

Summary



Camera: UltraCam Eagle, S/N UC-Eagle-1-50319383-f80

Manufacturer: Vexcel Imaging GmbH, A-8010 Graz, Austria

Date of Calibration: Jan-14-2016
Date of Report: Jan-28-2016
Revision of Camera: Rev03
Version of Report: V01

The following calibrations have been performed for the above mentioned digital aerial mapping camera:

- Geometric Calibration
- Verification of Lens Quality and Sensor Adjustment
- Radiometric Calibration
- Calibration of Defective Pixel Elements
- Shutter Calibration
- Sensor and Electronics Calibration

This equipment is operating fully within specification as defined by Vexcel Imaging GmbH.

Dr. Michael Gruber
Chief Scientist, Photogrammetry
Vexcel Imaging GmbH

Ing. Peter Prassl
Senior Calibration Engineer
Vexcel Imaging GmbH